


ALLOCATION OF COMPUTER CONNECTOR TRACKS

6 TRACK CONNECTOR (A)

- 1 Solenoid valve control
- 2 Fault warning light
- 3 Compressor feed
- 4 Not used
- 5 + 12V solenoid valve and thermal protection
- 6 Thermal protection feed

8 TRACK CONNECTOR (B)

- 1 - before ignition feed
- 2 Tailgate switch
- 3 Level sensor
- 4 + after ignition feed
- 5 Door switches
- 6 Level sensor
- 7 Earth
- 8 + before ignition feed



MA10353R